



Trends and Innovation of Infrared Semiconductor Laser based Chemical Sensing Technologies

F.K. Tittel, Y. Bakhirkin, R.F. Curl, A.A. Kosterev, R. Lewicki, S. So, D.Thomaszy and G. Wysocki

Rice Quantum Institute, Rice University, Houston, TX, USA

<http://ece.rice.edu/lasersci/>

OUTLINE

CUT

Goslar

July 21, 2008

- Motivation: Wide Range of Chemical Sensing
- Fundamentals of Laser Absorption Spectroscopy
- New Laser Sources and Sensing Technologies
- Selected Applications of Trace Gas Detection
 - Quartz Enhanced L-PAS (NH₃, Freon 125, acetone & TATP)
 - Nitric Oxide Detection (Faraday Rotation Spectroscopy, Remote Sensing and Cavity Enhanced Spectroscopy)
- Future Directions and Conclusions

Work supported by NSF, NASA, DOE and Robert Welch Foundation

Wide Range of Trace Gas Sensing Applications

- **Urban and Industrial Emission Measurements**
 - Industrial Plants
 - Combustion Sources and Processes (e.g. fire detection)
 - Automobile, Truck, Aircraft and Marine Emissions
- **Rural Emission Measurements**
 - Agriculture & Forestry, Livestock
- **Environmental Monitoring**
 - Atmospheric Chemistry
 - Volcanic Emissions
- **Chemical Analysis and Industrial Process Control**
 - Petrochemical, Semiconductor, Nuclear Safeguards, Pharmaceutical, Metals Processing, Food & Beverage Industries
- **Spacecraft and Planetary Surface Monitoring**
 - Crew Health Maintenance & Life Support
- **Applications in Health and Life Sciences**
- **Technologies for Law Enforcement and National Security**
- **Fundamental Science and Photochemistry**


Sensitivity Enhancement Techniques for Laser Spectroscopy

- **Optimum Molecular Absorbing Transition**
 - Overtone or Combination Bands (NIR)
 - Fundamental Absorption Bands (MID-IR)
- **Long Optical Pathlength**
 - Multipass Absorption Cell (White, Herriot)
 - Cavity Enhanced and Cavity Ringdown Spectroscopy
 - Open Path Monitoring (with retro-reflector): Standoff and Remote Detection
 - Fiberoptic Evanescent Wave Spectroscopy
- **Spectroscopic Detection Schemes**
 - Frequency or Wavelength Modulation
 - Balanced Detection
 - Zero-air Subtraction
 - Photoacoustic Spectroscopy
 - Laser Induced Breakdown Spectroscopy (LIBS)





Key Characteristics of mid-IR QCLs and ICL Sources-2008


- **Band – structure engineered devices**
(emission wavelength is determined by layer thickness – MBE or MOCVD);
mid-infrared QCLs operate from 3 to 24 μm (AlInAs/GaInAs)
- Compact, reliable, stable, long lifetime, and commercial availability
- Fabry-Perot (FP), single mode (DFB) and multi-wavelength
- **Spectral tuning range in the mid-IR**
(4-24 μm for QCLs and 3-5 μm for ICLs)
 - 1.5 cm^{-1} using injection current control
 - 10-20 cm^{-1} using temperature control
 - > 200 cm^{-1} using an external grating element and heterogeneous cascade active region design; also QC laser array (Harvard)
- **Narrow spectral linewidth**
 - CW: 0.1 - 3 MHz & <10Khz with frequency stabilization (0.0004 cm^{-1})
 - Pulsed: ~ 300 MHz (chirp from heating)
- **High pulsed and cw powers of QCLs and ICLs at TEC/RT temperatures**
 - Pulsed and CW powers of ~ 1.5 W; high temperature operation ~300 K
 - >50 mW, TEC CW DFB @ 5 and 10 μm
 - > 600 mW (CW FP) @ RT; wall plug efficiency of ~15.% at 4.6 μm ;
 - Princeton, Northwestern, Harvard, ETH, NRL, FI-IAF, UMBC,
 - commercialization by Adtech Optics, Pranalytica, Alpes, DLS, Alcatel Thales, Nanoplus, Laser Components, Maxion, Corning, Hammamatsu




4 mm



From conventional PAS to QEPAS



Quartz Tuning Fork as a Resonant Microphone




Unique properties

- Extremely low internal losses:
 - $Q \sim 10\,000$ at 1 atm
 - $Q \sim 100\,000$ in vacuum
- Acoustic quadrupole geometry
 - Low sensitivity to external sound
- Large dynamic range – linear from thermal noise to breakdown deformation
 - 300K noise: $x \sim 10^{-11}$ cm
 - Breakdown: $x \sim 10^{-2}$ cm
- Wide temperature range: from 1.56K (superfluid helium) to ~ 700 K
- Low cost ($< \$1$)

Other parameters

- Resonant frequency ~ 32.8 kHz
- Force constant ~ 26800 N/m
- Electromechanical coefficient $\sim 7 \times 10^{-6}$ C/m

Absorption Detection Module for QEPAS Gas Sensor



Microresonator tubes


- Must be close to the QTF but not touching TF (i.e. 30-50 μm gaps).
- Inner diameter 0.41 mm; 10% lower signal with 0.6 mm diameter tubes.
- Each tube $\sim 5\text{mm}$ long ($\sim \lambda/2$ for sound at 32.8 kHz) ?

Gain: $\times 10$ to $\times 20$

Windows

- Must be tilted to prevent the reflected light from entering the microresonator tubes.
- Exact positioning is not critical

Typical QTF Resonance Curves




Merits of QEPAS based Trace Gas Detection



- Ultra-compact; small sample volume - $<1\text{mm}^3$
- Rugged and low cost transducer – quartz monocrystal
- High immunity to environmental acoustic noise
- Sensitivity is limited by the fundamental thermal TF noise – $k_B T$ energy in the TF symmetric mode, directly observed
- White noise spectrum – SNR scaling as \sqrt{t} up to $t=3$ hours was observed
- High Sensitivity (ppm to sub ppb) and excellent dynamic range
- Applicable over a wide range of pressures
- Temperature, pressure and humidity insensitive

Overlapping NIR absorption bands





Data coming
5 μm (Ak)

~~DL~~

DLS... Array



↓

DLS EC-QCL based QEPAS Sensor




54 cm^{-1}
944 cm^{-1}
10.6 μm
34 mW.

Tunable external cavity QCL based spectrometer



- Fine wavelength tuning
 - PZT controlled EC-length
 - PZT controlled grating angle
 - QCL current control
- Motorized coarse grating angle tuning
- Vacuum tight QCL enclosure with build-in 3D lens positioner (TEC laser cooling + optional chilled water cooling)

Performance of 8.4 μm cw EC-QCL Spectroscopic Source



Tunability **182 cm^{-1}** @ $8.4\text{ }\mu\text{m}$; (1100 to 1280 cm^{-1}); $\lambda_c=15\%$

AR coating:

$R_{\text{AR}} \approx 2 \times 10^{-4}$



$P_{\text{EC-opt}} : \sim 50\text{ mW @ } -30\text{ C}$, ; also

$103\text{ mW @ } 8.3\text{ }\mu\text{m \& } -25\text{ C}$;

$\sim 700\text{mA}$; 2007 QCL technology



PHOTONS v4.0 - 2.7 μ m CO₂ Direct Absorption Based Sensor




- Small size
- Relatively low cost
- High efficiency switching power supplies
- PWM Peltier cooler driver
- 0.2W control system power consumption
- Detection sensitivity of CO₂ 1 ppm with 1sec. lock-in time constant
- Over 100x improvement in sensitivity is possible @ 4.2 μ m

Custom Multipass Cell based TDLAS Platform

- Designed for TO5 Packaged Lasers with Integrated TEC
- Wavelength modulation capability (scan, 1f, or 2f)
- Quadrature lock-in amplifier
- Low noise current driver
- TEC driver, 0.001 °C stability
- Battery Powered

*rapid prototyping / fused deposition model
side plastic jet.*

Wireless Networking Module



ULN $\sim 0.75 \text{ mW}$ \$400

TDLAS with a 763nm VCSEL measuring O₂

