



Motivation for Nitric Oxide Detection

- · Atmospheric Chemistry
- · Environmental pollutant gas monitoring
 - NO_x monitoring from automobile exhaust and power plantemissions
 - Precursor of smog and acid rain
- · Industrial process control
- NO in medicine and biology
 - Important signaling molecule in physiological processes in humans and mammals (1998 Nobel Prize in Physiolog/Medicine)
 - Treatment of asthma, COPD, acute lung rejection
- Photofragmentation of nitro-based explosives (TNT)

Quartz Tuning Fork as a Resonant Microphone Unique properties Extremely low internal losses: Q-10 000 at 1 atm Q-100 000 in vacuum Acoustic quadrupole geometry Low sensitivity to external sound Large dynamic range (-106) – linear from thermal noise to breakdown deformation 300K noise: x-10⁻¹¹ cm Breakdown: x-10⁻² cm Wide temperature range from 1.56K (superfluid helium) to -700K Low cost (<\$1) Other parameters Resonant frequency -32.8 kHz Force constant -26800 N/m Electromechanical coefficient -7*10-6 C/m





Merits of QEPAS based Trace Gas Detection Very small sensing module and sample volume (a few mm³ to ~2cm²) Extremely low dissipative losses Optical detector is not required Wide dynamic range Frequency and spatial selectivity of acoustic signals Rugged transducer — quartz monocrystal; can operate in a wide range of pressures and temperatures Immune to environmental acoustic noise, sensitivity is limited by the fundamental thermal TF noise k_BT energy in the TF symmetric mode Absence of low-frequency noise: SNR scales as √t, up to t=3 hours as experimentally verified QEPAS: some challenges Cost of Spectrophone assembly

Responsivity depends on the speed of sound and molecular energy


RICE


Sensitivity scales with laser power


Effect of H₂O


transfer processes


Cross sensitivity issue






































Summary and Outlook A 5 26 µm and 7 .24 µm CW TEC HHL packaged DFB-QCL based QEPAS sensor for NO and SO₂ detection was demonstrated. For interference free NO absorption line located at 1900.08 cm ¹ a 1 o minimum detection limit of 3 ppbv was achieved at a gas pressure of 240 Torr and sampling time of 1 sec. A 1 o minimum detection limit of 100 ppbv was achieved at a gas pressure of 100 Torr and sampling time of 1 sec for a SO₂ absorption line at 1380.94 cm ¹. After adding water vapor to analyzed SO₂ mixture more than 3 times improvement in detected signal was observed. Laser spectroscopy with a mid-infrared, room temperature, continuous wave, high performance DFB QCL is a promising analytical approach for real time atmospheric measurements and breath analysis. Future tasks for the SO₂ will include line locking for long term measurements as well as using a high power QCL (=200 mW) operating at strongest SO₂ absorption line at 1348 cm ¹. Compact, robust semsitive and selective QCL based QEPAS sensor technology offers a promising future to perform real-time environmental, biomedical and industrial emission measurements.

